

# **User Manual**

## **User Manual**

G32A1465 EVAL Board

Version: V1.0

© Geehy Semiconductor Co., Ltd.



#### Contents

1	Introduction2						
	1.1	G32A Ecosystem	2				
	1.2	Evaluation board	2				
2	Functi	on overview	4				
	2.1	Power supply control	4				
	2.2	Clock	4				
	2.3	Reset	4				
	2.4	Simulation interface	4				
	2.5	LED	4				
	2.6	Keys	4				
	2.7	CAN	5				
	2.8	LIN	5				
3	SDK (	Dverview	6				
	3.1	On-board driver	6				
	3.2	Library files	6				
	3.3	Middleware	6				
	3.4	Routine	6				
	3.5	IDE support	6				
4	IDE de	ebugging	7				
	4.1	KEIL debugging	7				
	4.2	IAR debugging	13				
5	Refere	ences	18				
6	Revisi	on History	19				



## 1 Introduction

This User Manual introduces the functions, onboard resources, and supporting SDK of the G32A1465 evaluation board.

## 1.1 G32A Ecosystem

The G32A ecosystem includes product application solution, hardware development board, download simulation tool, development tool chain and SDK. Moreover, the development tool chain is suitable for many development tools at home and abroad, such as Keil-MDK, and IAR for Arm, and all of them are equipped with relevant enginering in the SDK to meet the needs of different users in different platforms.




Figure 1 G32 Ecosystem

## 1.2 Evaluation board

The G32A1465 evaluation board is a complete demonstration and development platform for G32A1465 MCU, and it is equipped with a G32A1465 MCU chip. The chip is based on Arm<sup>®</sup> Cortex<sup>®</sup> -M4 core, with an operating frequency of 112MHz, Flash 1024KB. This evaluation board has rich peripheral functions and is equipped with EVAL SDK, which can help developers efficiently evaluate chip performance or develop related applications.





#### Figure 2 G32A1465 EVAL Baseboard

Table 1 Component Composition Table	Table 1	Component	Compositior	n Table
-------------------------------------	---------	-----------	-------------	---------

Component name	Description
J1, J2, J3, J4, J5, J6	Pin output
G32A1465	MCU
LED	RGB tricolor light (PTD15-Green, PTD16-Blue, PTD0-Red)
KEY1	Reset key
KEY2, KEY3	PTC13, PTC12
RV1 potentiometer	PTC14 (ADC0)
U4 CAN transceiver	PTE4/PTE5 (CAN RX/TX)
U5-LIN transceiver	PTD6/PTD7/PTE9 (LIN RX/LIN_SLP/TX)
U6-CH340E	USB-to-serial port RX/TX
J9, J10	PTC7, PTC6 (UART TX/RX)
J13	MCU power supply selection 3.3V/5V
J14	JTAG
K3	ON/OFF 12V power supply



## 2 Function overview

The G32A1465 evaluation board includes the following peripheral functions, and can be used together with SDK to help developers evaluate the chip performance or develop related applications.

- 1. CAN
- 2. LIN
- 3. USB to UART
- 4. Key×3
- 5. RGB LED

## 2.1 **Power supply control**

The G32A1465 evaluation board can be powered by an external 12V power adapter or through USB; the JTAG/SWD interface can provide 3.3V power supply to MCU; MCU power supply option (J13 5V/3.3V) is reserved on the evaluation board.

## 2.2 Clock

The onboard 8MHz external clock is used for G32A1465.

## 2.3 Reset

Provide KEY1 reset key and JTAG reset signal.

### 2.4 Simulation interface

Standard 20-pin IDC JTAG connecting interface.

## 2.5 LED

Onboard D1 power indicator light, D6 tri-color light.

### 2.6 Keys

Provide 2 IO pull-down keys.



## 2.7 CAN

Provide CAN transceiver interface, requiring a 5V power supply system.

### 2.8 LIN

Provide LIN transceiver interface, requiring an additional 12V power supply.



## 3 SDK Overview

SDK is provided in the compressed package form, and it includes the onboard driver packages such as basic LED, Button, and COM port drivers, as well as multiple necessary libraries such as G32A1465 standard library and peripheral driver library. It also includes many routines easy to reuse, such as ADC sampling, CAN/CANFD transmitting and receiving, and CRC check.

## 3.1 On-board driver

The onboard driver files are located in the "Boards" folder, and they provide the KEY, LED, and COM drivers for the G32A1465 evaluation board.

## 3.2 Library files

The library files are located in the "Libraries" folder, and they provide the core driver files and peripheral driver files for the G32A1465 evaluation board.

### 3.3 Middleware

The middleware files are located in the "Middlewares" folder and are some third-party tools or source codes used in the demo provided by the G32A1465 board.

## 3.4 Routine

SDK package includes many applications easy to reuse, such as ADC sampling, CAN/CANFD transmitting and receiving, and CRC check. This chapter will give a brief introduction to the demo provided by the G32A1465 evaluation board.

## 3.5 IDE support

All the demos provided by the G32A14665 evaluation board support IAR for Arm and Keil MDK.



## 4 IDE debugging

## 4.1 KEIL debugging

Step 1: Power the evaluation board① Supply power through USB port






② Supply power by a 12V power adapter





Step 2: Debug with J-LINK in KEIL environment Download SDK locally and install KEIL

①Connect J-LINK to PC



#### 2 Open the KEIL engineering under SDK

👻 ↑ 📜 « Exar	mples > G32A1465 > ADC > ADC_HardwareC	ompare > Project > MDK	ن v ی	在 MDK 中搜索		
E ^	名称 ^	修改日期	类型	大小		
📜 E	Listings	2024/7/16 17:05	文件夹			
📕 F	Out	2024/7/16 17:05	文件夹			
📕 F	ADC HardwareCompare.uvguix.123	2024/8/7 14:55	123 文件	176 KB		
1 L	ADC_HardwareCompare.uvoptx 创建日期: 2 大小: 1.18	2024/7/16 17:05 MR	UVOPTX 文件	13 KB		
ι.	MDC_HardwareCompare.uvprojx 文件夹: G3	2A1465 4:01	礦ision5 Project	18 KB		
L	EventRecorderStub.scvd	2024/8/7 14:54	SCVD 文件	1 KB		
L .	JLinkLog.txt	2024/8/7 14:55	文本文档	25 KB		
1	🕢 JLinkSettings.ini	2024/8/7 14:54	配置设置	1 KB		
P						
P					选择要预览的文件。	
P						
📜 R						
R R						
📜 Т						
📕 V						
📕 G3						
Δ 🧾						



③ Open the post-engineering interface

E:\05 Work\01.Document\06 work list	debug programs\G32A14XX SDK 0425\G32A1xxx_SDK_V1.1\Examples\G32A1465\ADC\ADC_HardwareCompare\Project\MDK\ADC_HardwareCompar	- 0 ×
File Edit View Project Flash Debu	g Peripherals Tools SVCS Window Help	
n 💕 🖬 🏈 🕺 🛍 🛍 🔊 e	← →   隆 隐 隐 译 准 ///////////////////////////////	
🔮 🕮 🏙 🗳 - 🧮 🙀 🛱 G32A1465	🗹 🔊 🛔 🖻 🗢 🗢 🏟	
Project 📮 🖬	main.c	<b>▼</b> ×
Project: ADC_HardwareCompare     G3201455     G G3201455     G G4015     G4015     G G4015     G4	<pre>31 []/** 8adtogroup G32A1465_Examples 32 8 33 8 34 9 35 []/** 8adtogroup ADC_HardwareCompare 35 1 4; 36 ] /** 8adtogroup ADC_HardwareCompare_Macros Macros 36 ] /** 8adtogroup ADC_HardwareCompare_Macros Macros 37 1 4; 38 fdefine ADC_INSTANCE (00) 48 fdefine ADC_INSTANCE (00) 49 fdefine ADC_INSTANCE (00) 40 fdefine ADC_INSTANCE (00) 41 fdefine ADC_INSTANCE (00) 42 fdefine ADC_INSTANCE (00) 43 fdefine ADC_INSTANCE (00) 44 fdefine ADC_INSTANCE (00) 45 fdefine ADC_INSTANCE (00) 45 fdefine ADC_INSTANCE (00) 46 fdefine ADC_INSTANCE (00) 47 fdefine ADC_INSTANCE (00) 48 fdefine ADC_INSTANCE (00) 49 fdefine ADC_INSTANCE (00) 49 fdefine ADC_INSTANCE (00) 40 fdefine ADC_INSTANCE (00) 41 fdefine ADC_INSTANCE (00) 42 fdefine ADC_INSTANCE (00) 43 fdefine ADC_INSTANCE (00) 44 fdefine ADC_INSTANCE (00) 45 fdefine ADC_INSTANCE (00) 45 fdefine ADC_INSTANCE (00) 45 fdefine ADC_INSTANCE (00) 46 fdefine ADC_INSTANCE (00) 47 fdefine ADC_INSTANCE (00) 48 fdefine ADC_INSTANCE (00) 49 fdefine ADC_INSTANCE (00) 49 fdefine ADC_INSTANCE (00) 40 fdefine ADC_INSTANCE (0</pre>	
■ Pro  Bo   {} Fu   0, Te		>
Build Output		4 🖬
		^
		~
<		3
	J-LINK / J-TRACE Cortex L:1 C:1	CAP NUM SCRL OVR R /W

#### ④ Compile the engineering

😨 E:\05 Work\01.Document\06 work lis	st\debug programs\G32A14XX SDK 0425\G32A1xxx_SDK_V1.1\Examples\G32A1465\ADC\ADC_Harc	dwareCompare\Project\MDK\ADC_HardwareCompar	- 0 X
File Edit View Project Flash Deb	ug Peripherals Tools SVCS Window Help		
🗋 💕 🖬 🏈 🕉 🖻 🖏 🔊 (	*   ← →   陀 隐 隐 读   译 译 //: //::  🦉 CAN_HW_GetMbValues 🔜 🗟 🌮   🍳 •   🌢	) o 🔗 🍓 -   🔤 - 🔍	
🥩 🕮 🕮 🏈 • 📖 🙀 🛛 G32A14	55 🔍 🔊 📩 🖷 💠 🐡 🏨		
Project 🛛 🛱 🔣	main.c		<b>▼</b> ×
<ul> <li>Project: ADC_HardwareCompare</li> <li>G32A1465</li> <li>CMSIS</li> <li>Application</li> <li>main.c</li> <li>g32a1xxx_int.c</li> <li>user_adc_config.c</li> <li>User_adc_config.c</li> <li>SSIF</li> <li>SSI</li> <li>Board</li> </ul>	<pre>31 ⊟ /** @addtogroup G32A1465_Examples 32 0; 33 */ 34 35 ⊟ /** @addtogroup ADC_HardwareCompare 36 0; 37 */ 38 /** @defgroup ADC_HardwareCompare_Macros Macros 39 0; 40 */ 41 42 /* ADC instance */ 43 fdefine ADC_INSTANCE (0U) 44 45 /**@) end of group ADC_HardwareCompare_Macros*/ 46 47 ⊟ /** @defgroup ADC_HardwareCompare_Variables Variables 48 0; 49 1; </pre>		*
Build Output Build target 'G32A1465'	<pre>50 static_IO uint32_t g_timingDelay; 51 float g_addwiXvlue = 4096; 52 float g_addwifference = 3.3f; 53 bool g_compareFlag; 54 55 /**8) end of group ADC_HardwareCompare_Variables*/ 42 Compare.axf* - 0 Error(s), 0 Warning(s). 0</pre>		* * 0 *
	J-LINK / J-TRAC	E Cortex L1 C:1	CAP NUM SCRL OVR R /W
		L'INT	Sent Dent Dent OTA A/IT



The france will a general factor and	st\debug programs\G32A14XX SDK 0425\G32A1xxx_SDK_V1.1\Examples\G32A1465\ADC\ADC_HardwareCompare\Project bug Periphenals Tools SVCS Window Help	\MDK\ADC_HardwareCompar — 🗇 🗙
n 🗃 🖬 🌒 🛦 🖻 🙇 🤊	(*) 수 => (*) 隐 隐 摩 譯 //: //: 🞯 CAN_HW_GetMbValues 🗟 💸 🍳 - ) • O 🔗 🛃 - 🔳	- 2
🥩 🕮 🕮 🌳 - 📖 🕅 🙀 🛛 G32A14	165 🗸 🕅 🚠 🖶 🗇 🏟	
Project 🏾 🛛 🖬	V Options for Target 'G32A1465'	<b>▼</b> ×
Project: ADC, HardwareCompare  Ga2A1465  Ga2A1465  Ga2A1465  Gaana CMSIS  Gaana CMSIS  Gaana CMSIS  Gaana G	Device       Target       Odput       Lating       User       C/C++ (AC6)       Am       Linker       Debug       Uitites         Software Packs	
Pro      Bo      Fu      D	OK Cancel Defaults Help	~
Build Output		4 🖬
Build target 'G32A1465'	Compare.axf" - 0 Error(s), 0 Warning(s).	^
Build Time Elapsed: 00:00:0		v
¢	I-LINK / I-TRACE Cortex	LET CET CAP NUM SCRI OVR R AW

#### (5) Click the Option button and select the chip model suitable for the SDK

#### 6 Select the debugging hardware tool J-LINK in the option interface and click "Settings"

- 0 E:\05 Work\01.Docume nt\06 work list\debug programs\G32A14XX SDK 0425\G32A1xxx\_SDK\_V1.1\Examples\G32A1465\ADC\ADC\_HardwareCompare\Project\MDK\ADC\_HardwareCompar Tile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools SVCS Window Help

Pile Edit View Project Flash Debug Peripherals Tools 
 Image: Construction of the second 🔜 🛠 🖨 着 🖏 🔜 Project • × × Project: ADC\_HardwareCompare
 G32A1465 Device | Target | Output | Listing | User | C/C++ (AC6) | Asm | Linker Debug | Utilities | C Use Simulator with restrictions Settings G Use: J-LINK / J-TRACE Cortex ▼ Settings Initialization File: .... Edit... ... Edt... Restore Debug Session Settings ore De ssion Setting 🕀 🧰 OSIF bug Ser Breakpoints 
 Toolbox
 Watch Windows & Performance Analyzer
 Memory Display 
 System Viewer 
 Image: Toolbox
 Image: Toolbox

 Image: Watch Windows
 Image: Tracepoints

 Image: Memory Display
 Image: System Viewer
 🕀 🧰 Std 🗉 🧰 Board Driver DLL: CPU DLL: Parameter Paramet Dialog DLL: Dialog DLL: Parameter DCM.DLL PCM4 Para pCM4 TCM.DLL Warn if outdated Executable is loaded Warn if outdated Execut Manage Component Viewer Description Files ... Pro... () Fu... | 0, Te. OK Cancel Defaults Help > Build Output 4 🖬 Build target 'G32A1465' Build target 'G32A1465' \*.\Out\G32A1465\ADC\_HardwareCompare.axf" - 0 Error(s), 0 Warning(s). Build Time Elapsed: 00:00:00 L1 C1 CAP NUM SCRL OVR R /W J-LINK / J-TRACE Cortex



#### $\ensuremath{\textcircled{}}$ After clicking, the debugging tools can be identified

	unde liet datum neuronanic 23A14YY CDV DASELC 23A1000 CDV VI 11Euronales C23A146ELADCLADC Underson Comment Depjec	t\MDK\ADCHardwareCompar — 🗇 🗙
File Edit View Project Fla	Cortex JLink/JTrace Target Driver Setup ×	
🗎 🧉 🖬 🎒 🕺 🛍 🛍	Debug Trace Flash Download	• 4
🕹 🖽 🕮 🔹 - 📖 🞇 📗	J-Link / J-Trace Adapter SW Device	
Project	SN: 501012352 V IDCODE Device Name Move	<b>▼</b> ×
🖃 🔧 Project: ADC_HardwareCo	SWD @0x28401477 APM CoreSight SW-DP	^
🖂 💭 G32A1465	Device: J-Link SWDI O 0x2BA01477 ARM Coresignt SW-DP	
E CMSIS	HW : V12.00 dll : V7.94	
Application	FW : J-Link V12 compiled Apr 23	
g32a1xxx_int.c	Port: Max & Automatic Detection ID CODE:	
. user_adc_confi	SW  ID MHz C Manual Configuration Device Name:	
🖲 🧰 OSIF	Auto Clk Add Delete Update IR len:	
🕀 🧰 Std		
🖲 🧰 Board		
	Connect & Reset Options Cache Options Download Options	
	Connect: Normal 💽 Reset: Normal 💽 🔽 Cache Code 🗌 Verify Code Download	
	I Reset after Connect I Cache Memory □ Download to Flash	
	Interface TCP/IP Misc	
	© USB © TCP/IP Network Settings	
	IP-Addrest Port (Auto: Autodetect JLink Info	
•	Scan 127.0.0.1:0	×
🖻 Pro 🚷 Bo   {} Fu   0.	Ping JLink Cmd	>
Build Output	State: ready	# 🖬
Build target 'G32A1465		^
".\Out\G32A1465\ADC_Ha: Build Time Elapsed: 04		
surra rime stapsed. of	<b>确定 取満</b> 应用(A)	v
د ا	LUNK / LTRACE Contex	1:1 C1 CAP NUM SCRI OVR R W


#### ⑧ After confirming the option, click Debug to start the debugging process

EXOS Work/01.Document/06 work list/debug programs/G32A14XX SDK 0425/G32A1xxx\_SDK //1.1/Examples/G32A1465/ADC/ADC\_HardwareCompare/Project/MDK/ADC\_HardwareCompare - 0 × File Edit View Project Flash Debug Peripherals Tools SVCS Window Help

			「「「「「「」」」「「「」」」「「」」」「「」」」「「」」「「」」」「「」	
Registers	ф 🗵	Disa	ssembly	å 🔀
Register	Va 🔺		165: (	^
- Core			<pre>l66: float adcValue; l67:</pre>	
R0	Oxt		10: 168: /* Initialize clock */	~
R1 R2	Ox: Oxi	<		>
R2 R3	Ox(		main.c startup_g32a1465.5	<b>▼</b> ×
R4	Ox		160 * @param None	A
R5	0xI		161	
R6	Ox1 Ox1		162 * @retval None	
	Oxt		163 L */	
- R9	Oxt		164 int main(void) 165 — (	
R10	Oxt	Pr 1	166 float adcValue:	
R11	Oxt		167	
R12 R13 (SP)	Oxi Oxi		168 /* Initialize clock */	
R13 (SP)	UK. Ovi		<pre>169 CLOCK_SYS_Init(4g_clockConfig);</pre>	
R15 (PC)	0x1		170 171 /* LED init */	
	0x/		171 /* LED init */ 172 LED_Init();	
Banked			173	
System	_		174 /* UART init */	
Internal Mode	Th		175 COM_Init();	
Privilege	Pri		176	
Stack	M¢ 💌		177 /* ADC init */	*
🔚 Project 🛛 🚟 Re	gisters	<		>
Command			🗴 🔼 Call Stack + Locals	<b>#</b> 🛛
* JLink Info	Memory	y maj	p 'after startup completion point' is active	
< .			>	<u>^</u>
>				•
ASSIGN Break	isable	Brea	akEnable BreakKill BreakList BreakSet BreakAccess 🖓 Call Stack + Locals 🔲 Memory 1	
			J-LINK / J-TRACE Cortex t1: 0.02277110 sec L:165 C:1	CAP NUM SCRL OVR R /W




(9) The evaluation board light is on



## 4.2 IAR debugging

Step 1: Power the evaluation board The same as 4.1 Step 1; Step 2: Debug with J-LINK in IAR environment Download SDK locally and install IAR

① Connect J-LINK to PC





#### ② Open the IAR engineering under SDK

● E 合       名称       各称       修改日順       実型       大小         ● E 合       6321165       2024/8/714:56       文件実         ● String       2024/8/714:56       文件実         ● C 人場本がwareCompare.ewp       2024/8/714:51       文件実         ● ADC_HardwareCompare.ewp       2024/8/714:51       EWP 文件       79 KB         ● ADC_HardwareCompare.ewp       2024/8/714:01       EWP 文件       79 KB         ● ADC_HardwareCompare.ewp       2024/8/714:01       EWP 文件       79 KB         ● ADC_HardwareCompare.ewp       2024/8/714:01       EWP 文件       79 KB         ● ADC       HardwareCompare.ewp       2024/8/714:01       EWP 文H       79 KB         ● ADC       F       F       F       F       70 KB         ● ADC       F       F       F       F       70 KB         ● ADC       F       F       <	👻 🛧 📜 « Exampl	es > G32A1465 > ADC > ADC_HardwareCo	ompare > Project > IAR	v ت	在 IAR 中搜索		
> IF       Sock 1403       2024/0/1 14:36       文村夫         > Isettings       2024/0/1 14:56       文村夫         > IL       ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       ADC_HardwareCompare.ewp       2024/0/15 14:01       IAR IDE Workspace       1 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       Backup of ADC_HardwareCompare.ewp       2024/0/15 14:01       EWP 文件       79 KB         > IL       R       R       R       R       R       R         > V       G3       V       A       R       R       R         > IL       IL       IL       IL       I	> 📜 E ^ _ 쇧	称 ^	修改日期	类型	大小		
> ■ f       ■ settings       2024/8/7 14:56       文件共         > ■ DC_HardwareCompare.ewp       2024/4/15 14:01       EWP 交件       79 KB         ○ DAC_HardwareCompare.eww       2024/4/15 14:01       EWP 文件       79 KB         ○ E       Backup of ADC_HardwareCompare.ewp       2024/4/15 14:01       EWP 文件       79 KB         ○ L       ○       Backup of ADC_HardwareCompare.ewp       2024/4/15 14:01       EWP 文件       79 KB         ○ L       ○       Backup of ADC_HardwareCompare.ewp       2024/4/15 14:01       EWP 文件       79 KB         ○ L       ○       □       □       □       □       □         ○ L       □       □       □       □       □       □         ○ L       □       □       □       □       □       □         ○ L       □       □       □       □       □       □       □         ○ L       □       □       □       □       □       □       □       □         ○ P       □       □       □       □       □       □       □       □         ○ P       □       □       □       □       □       □       □       □         ○ V	> 🖡 E	G32A1465	2024/8/7 14:56	文件夹			
● ADC_HardwareCompare.ewv       2024/4/15 14:01       IAR IDE Workspace       1 KB         ● Backup of ADC_HardwareCompare.ewp       2024/4/15 14:01       EWP 文件       79 KB         ● L       -       -       -       -         ● L       -       -       -       -         ● Backup of ADC_HardwareCompare.ewp       2024/4/15 14:01       EWP 文件       79 KB         ● L       -       -       -       -         ● L       -       -       -       -         ● L       -       -       -       -         ● L       -       -       -       -         ● L       -       -       -       -         ● L       -       -       -       -         ● P       -       -       -       -         ● P       -       -       -       -         ● R       -       -       -       -       -         ● R       -       -       -       -       -       -         ● P       -       -       -       -       -       -       -         ● R       -       -       -       -       -       <							
3 ■ L Backup of ADC_HardwareCompare.ewp 2024/4/15 14:01 EWP 文件 79 KB 3 ■ L 4 ■ L 3 ■ L 3 ■ L 3 ■ L 3 ■ L 3 ■ L 4 ■ L 3 ■ L 3 ■ L 4 ■ L 3 ■ L 4 ■ L 3 ■ L 4	> 📕 F	ADC_HardwareCompare.ewp	2024/4/15 14:01	EWP 文件	79 KB		
2 ● L ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●	> 📕 L 🛛 🕻	ADC_HardwareCompare.eww	2024/4/15 14:01	IAR IDE Workspace	1 KB		
→ L → L → L → L → R → P → P → P → P → P → R → R → R → R → R → T → T → T → T → T → T → T → T	→ <u>∎ ι</u> [	Backup of ADC_HardwareCompare.ewp	2024/4/15 14:01	EWP 文件	79 KB		
<ul> <li>↓</li> <li></li></ul>	> 1 L						
→ L → K → K → P → P → R → R → R → R → R → T → G3 → K							
→ ■ N → ■ P → ■ P → ■ P → ■ P → ■ R → ■ R → ■ R → ■ R → ■ T → ■ V → ■ G3 → ■ A							
→ P 決特預20. → P 決特預20. → R → R → R → R → R → R → G3 → K							
→ 『 P 没有预阅。 → 『 P							
→ ■ P 没有预定。 → ■ R → ■ R → ■ R → ■ T → ■ V → ■ G3 → ■ A							
<ul> <li>&gt; I. P</li> <li>&gt; I. R</li> <li>&gt; I. T</li> <li>&gt; I. T</li> <li>&gt; I. V</li> <li>~ G3</li> <li>~ I. A</li> </ul>						25	2有预览。
> R > T > V • G3 • A							
> II T > II V ~ II G3 ~ II A							
> II V ~ I G3 ~ I A	> 📜 R						
G3	> 📜 T						
A 1 V	> 🧵 V						
	✓  ☐ G3						
	~ <b>]</b> A						
· •	× .						
	~						
	> 🗸	字节					

#### ③ Select the device model

ADC_HardwareCompare - IAR Embedded Work	bench IDE - Arm 9.30.1						- 1	o x	<
File Edit View Project J-Link Tools Window									
i 🗅 🗅 🔛 🚇 I 🖴 I 👗 🛍 🛅 I 🝮 🖒 I	•	< Q > ち 🖻 🔇	> < >	🗋 🏮 📼 🕻					
Workspace • A × mai	<ul> <li>Options for node "ADC_Ha</li> </ul>	ardwareCompare"				×			•
G32A1465 ~									f()
Files     Image: Compare - G       Image: Compare - G     Image: Compare - G       Imag	Category: General Options Static Analysis Runtime Checking C/C++ Compiler Assembler Output Converter Output Converter Output Converter	Library Configurati Target	on Library 32-bit	Options 1 64-bit	Library Options 2 Output				*
Here Std	Build Actions	Processor variant							
User_Config	I-jet J-Link/J-Trace TI Stellaris Nu-Link	<ul> <li>Core</li> <li>Device</li> <li>CMSIS-Pack</li> <li>Execution mode</li> <li>32-bit</li> </ul>	Cortex-M4 Geehy G32A146 None	5	<b>B</b> +				
ADC_HardwareCompare	PE micro ST-LINK	O 64-bit						Þ	-
Build	Third-Party Driver TI MSP-FET							<b>→</b> ņ	×
Messages Total number of errors: 0 Total number of warnings: 0	TI XDS							Line	•
Build succeeded									
Build Debug Log Ready				OK	Cancel		System 大写 数	字改写	-



#### ④ Click OK after confirming the tool information

ADC_HardwareCompare - IAR Embedded	d Workbencl	h IDE - Arm 9.30.1			- 8 ×
File Edit View Project J-Link Tools W	indow Help	Options for node "ADC Har			×
i 🗅 🗅 🖬 🗿 🔒 🕹 🛍 🗅 🖒 O	5	Options for node ADC_Har	rowareCompare		×
Workspace 👻 🖡 🗙	main.c >				
G32A1465 ~		Category:		Earl	f()
Files     Image: Compare - G., Image: Compare	₽./*	General Options Static Analysis Runtime Ohecking C/C++ Compiler Assembler Output Converter Custom Build Build Actions Linker Debugger	Setup Connection Breakpoints Reset Normal	- 0	ay sen ya
User_Config		Simulator	Auto	Clock setup	
ADC_HardwareCompare	int ₽ {	CADI CMSIS DAP GDB Server I-jet J-Link/J-Trace TI Stellaris Ny-Link PE micro ST-LINK Third-Party Driver TI MSP-RET	Initial         1000         kHz           O Fixed         1000         kHz           Adaptive         ETMETB         Prefer ETB	CPU clock: 112.0 MHz SWO clock: Auto 2000 kHz	
		TI XDS			
Build	_				<b>→</b> ↓ ×
Messages Total number of errors: 0 Total number of warnings: 0 Build succeeded				OK Cancel	
Build Debug Log				Errors 0. Warnin	ngs 0 Ln 160. Col 17 System 大写 数字 改写

#### (5) Compile the engineering

ADC_HardwareCompare - IAR Embed	Ided Workbench IDE - Arm 9.30.1	- 0	×
File Edit View Project J-Link Tools	Window Help		
: 🗅 🗅 🔛 🚇 📇 🕹 🛍 🗂 😓	> ♂		
Workspace 🗸 🗘			-
G32A1465 Files	<pre></pre>		f()
ADC_HardwareCompare - G	<pre>/* Obtain conversion results */ ADC_ReadChanResult(ADC_INSTANCE, 0u, &amp;partAdcValue);</pre>		
	<pre>return (float)partAdcValue; </pre>		
⊞ ■ Std ⊞ ■ User Config	@brief Main function		
L⊞ ■ Oser_comig	* @param None		
	<pre>int main(void) float adcValue; /* Initialize clock */</pre>		
	CLOCK_SYS_Init(&g_clockConfig);		
ADC_HardwareCompare			+ -
Build		•	ůх
Messages	File	Line	^
Total number of errors: 0 Total number of warnings: 0 Build succeeded			l
			-
Build Debug Log			
Ready	Errors 0, Warnings 0 Ln 160, Col 17 System	大写数字改写	-




6 Click "Download and debug" to perform the burning and debugging process

ADC_HardwareCompare - IAR Embedded	Workbench IDE - Arm 9.30.1	- 0	$\times$
File Edit View Project J-Link Tools Wit	ndow Help		
: 🗅 🖸 🔛 🕋 🔚 🕹 🖄 🛍 🗂 😓 😅	- < Q > \$\$ HE < Q > [] 🗈 📄 🖉 H		
Workspace 🔻 🗭 🗙	main.c x		*
G32A1465 ~			fo
Files ♥ ▲ <u>ADC Hardware/Compare G</u> ♥ ■ Application ■ a 322 lox, fitc ■ 6 Goards ■ 6 CoslS ■ 5 Std ■ 5 Std ■ 5 User_Contig ■ 0 Output	<pre>/* Obtain conversion fiag bits */ g_compareFlag = ADC_ReadConvCompleteFlag(ADC_INSTANCE,0); /* Obtain conversion results */ ADC_ReadChanResult(ADC_INSTANCE, 0u, &amp;partAdcValue); return (float)partAdcValue; }  /*! /* divide float function     #param None     #param None     #param None     #param None     #float adcValue; /* Initialize clock */     CLOCK SYS_Init(&amp;g_clockConfig); </pre>		
ADC_H ardwareCompare	4		+ -
Build		-	ųχ
Messages	File	Line	э
Total number of errors: 0 Total number of warnings: 0 Build succeeded			
Build Debug Log	raw/C2341W/CREADD/C2341w/CREW118/sample/C23446030/04/C Madura/Samp	       _	

#### ⑦ Click the Run button

ADC_HardwareCompare - IAR Embedde	rd Workbench IDE - Arm 9.30.1		- 0 ×
File Edit View Project Debug Disasse	mbly J-Link Tools Window Help		
1 🗅 🖸 🔛 🚇 🔚 🕹 🛍 🗂 😓 🤇	3   - < Q > \$ = < Q > 3   = 0   0   0   0 = 0 C Q	i •I • 0	🗂 🗕 🚽 🕴 ETH SUO 🕴 🛃 🖕
Workspace 🔻 🗰 🕇	X main.c x	*	Disassembly 👻 A 🗙
G3241465      Files	<pre>main() /* Obtain conversion flog bits */ g_compareFlag = ADC_ReadConvCompleteFlag(ADC_INSTANCE,0); /* Obtain conversion results */ ADC_ReadChankesUlt(ADC_INSTANCE, 0u, 8partAdcValue); return (float)partAddValue;</pre>	fo	Go b: Disassembly Ox4ee8: 0xf7ff 0xfc9 return (float)partAdcVa 0x4ee0: 0x6e00 0x0a1 0x4ef0: 0xee00 0x0a1 0x4ef4: 0xeeb8 0x0a4 0x4ef8: 0xb03 int main(void) ( main: Dx4efa: 0x4538 CLOCK_SYS_Int(Ka_clock) 0x4efc: 0x402 0x4efc: 0x402 0x4efc: 0x402 0x4fo2: 0x41b 0xfa8 IED_Int(); 0x4f66: 0xf7ff 0xfe8. COM(nnt();
ADC_HardwareCompare		+ <b>v</b>	0x4f0a: 0xf7ff 0xfee
Debug Log			- 4 ×
Log Thu Aug 08, 2024 10:38:21: Reset Hi Thu Aug 08, 2024 10:38:21: Reset Hi Thu Aug 08, 2024 10:38:21: Reset Ry Thu Aug 08, 2024 10:38:21: Targetre			~
Build Debug Log	Errors 0. Warning	as 0 Ln 164.	Col 1 System 大写 数字 改写







## 5 References

The chip specification and peripheral details can be seen in the *G32A1465 User Manual*, *G32A1465 Datasheet*,

and *G32A1465 Schematic Diagram*. For more technical support, please visit our official website: <u>www.geehy.com</u>.



## 6 Revision History

Date	Revision	Changes
August 2024	1.0	New edition



### Statement

This document is formulated and published by Geehy Semiconductor Co., Ltd. (hereinafter referred to as "Geehy"). The contents in this document are protected by laws and regulations of trademark, copyright and software copyright. Geehy reserves the right to make corrections and modifications to this document at any time. Read this document carefully before using Geehy products. Once you use the Geehy product, it means that you (hereinafter referred to as the "users") have known and accepted all the contents of this document. Users shall use the Geehy product in accordance with relevant laws and regulations and the requirements of this document.

#### 1. Ownership

This document can only be used in connection with the corresponding chip products or software products provided by Geehy. Without the prior permission of Geehy, no unit or individual may copy, transcribe, modify, edit or disseminate all or part of the contents of this document for any reason or in any form.

The "极海" or "Geehy" words or graphics with "®" or "<sup>TM</sup>" in this document are trademarks of Geehy. Other product or service names displayed on Geehy products are the property of their respective owners.

#### 2. No Intellectual Property License

Geehy owns all rights, ownership and intellectual property rights involved in this document.

Geehy shall not be deemed to grant the license or right of any intellectual property to users explicitly or implicitly due to the sale or distribution of Geehy products or this document.

If any third party's products, services or intellectual property are involved in this document, it shall not be deemed that Geehy authorizes users to use the aforesaid third party's products, services or intellectual property. Any information regarding the application of the product, Geehy hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party, unless otherwise agreed in sales order or sales contract.



#### 3. Version Update

Users can obtain the latest document of the corresponding models when ordering Geehy products.

If the contents in this document are inconsistent with Geehy products, the agreement in the sales order or the sales contract shall prevail.

#### 4. Information Reliability

The relevant data in this document are obtained from batch test by Geehy Laboratory or cooperative third-party testing organization. However, clerical errors in correction or errors caused by differences in testing environment may occur inevitably. Therefore, users should understand that Geehy does not bear any responsibility for such errors that may occur in this document. The relevant data in this document are only used to guide users as performance parameter reference and do not constitute Geehy's guarantee for any product performance.

Users shall select appropriate Geehy products according to their own needs, and effectively verify and test the applicability of Geehy products to confirm that Geehy products meet their own needs, corresponding standards, safety or other reliability requirements. If losses are caused to users due to user's failure to fully verify and test Geehy products, Geehy will not bear any responsibility.

#### 5. Legality

USERS SHALL ABIDE BY ALL APPLICABLE LOCAL LAWS AND REGULATIONS WHEN USING THIS DOCUMENT AND THE MATCHING GEEHY PRODUCTS. USERS SHALL UNDERSTAND THAT THE PRODUCTS MAY BE RESTRICTED BY THE EXPORT, RE-EXPORT OR OTHER LAWS OF THE COUNTRIES OF THE PRODUCTS SUPPLIERS, GEEHY, GEEHY DISTRIBUTORS AND USERS. USERS (ON BEHALF OR ITSELF, SUBSIDIARIES AND AFFILIATED ENTERPRISES) SHALL AGREE AND PROMISE TO ABIDE BY ALL APPLICABLE LAWS AND REGULATIONS ON THE EXPORT AND RE-EXPORT OF GEEHY PRODUCTS AND/OR TECHNOLOGIES AND DIRECT PRODUCTS.

#### 6. Disclaimer of Warranty

THIS DOCUMENT IS PROVIDED BY GEEHY "AS IS" AND THERE IS NO WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT



NOT LIMITED TO, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT PERMITTED BY APPLICABLE LAW.

GEEHY'S PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED FOR USE AS CRITICAL COMPONENTS IN MILITARY, LIFE-SUPPORT, POLLUTION CONTROL, OR HAZARDOUS SUBSTANCES MANAGEMENT SYSTEMS, NOR WHERE FAILURE COULD RESULT IN INJURY, DEATH, PROPERTY OR ENVIRONMENTAL DAMAGE.

IF THE PRODUCT IS NOT LABELED AS "AUTOMOTIVE GRADE," IT SHOULD NOT BE CONSIDERED SUITABLE FOR AUTOMOTIVE APPLICATIONS. GEEHY ASSUMES NO LIABILITY FOR THE USE BEYOND ITS SPECIFICATIONS OR GUIDELINES.

THE USER SHOULD ENSURE THAT THE APPLICATION OF THE PRODUCTS COMPLIES WITH ALL RELEVANT STANDARDS, INCLUDING BUT NOT LIMITED TO SAFETY, INFORMATION SECURITY, AND ENVIRONMENTAL REQUIREMENTS. THE USER ASSUMES FULL RESPONSIBILITY FOR THE SELECTION AND USE OF GEEHY PRODUCTS. GEEHY WILL BEAR NO RESPONSIBILITY FOR ANY DISPUTES ARISING FROM THE SUBSEQUENT DESIGN OR USE BY USERS.

7. Limitation of Liability

IN NO EVENT, UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL GEEHY OR ANY OTHER PARTY WHO PROVIDES THE DOCUMENT AND PRODUCTS "AS IS", BE LIABLE FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, DIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE DOCUMENT AND PRODUCTS (INCLUDING BUT NOT LIMITED TO LOSSES OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY USERS OR THIRD PARTIES). THIS COVERS POTENTIAL DAMAGES TO PERSONAL SAFETY, PROPERTY, OR THE ENVIRONMENT, FOR WHICH GEEHY WILL NOT BE RESPONSIBLE.

#### 8. Scope of Application

The information in this document replaces the information provided in all previous versions of the document.

© 2024 Geehy Semiconductor Co., Ltd. - All Rights Reserved

### Geehy Semiconductor Co., Ltd. &+86 756 6299999 @www.geehy.com 🖂 contact@geehy.com